

INSTRUCTIONS

This unit is made for display purposes and should not be regarded as a toy.
Read the following carefully to ensure satisfactory and safe operation of this unit.
Please keep this instruction for future reference.

Feature:

1. This item is operated with 3 x AAA size batteries. (Not included)
2. Battery powered LED lights for the light source of the product.
3. Cord-free decoration piece, can easily be displayed anywhere indoor.
4. Power-saving LED can ensure longer battery life.

Operating procedure:

1. Carefully remove all packing material such as tags, fasteners, strings, etc.
2. Find the battery compartment at the bottom of the unit .
3. Open battery compartment lid
4. Insert 3 x AAA size batteries with the correct polarity. (see Fig 1)
Alkaline batteries are strongly recommended for the best performance.
Close the battery compartment lid.
5. Move the ON/OFF switch to the ON position to illuminate the light.
6. To extend the battery life, always switch the unit OFF when not in use.




Fig 1

Attention:

1. Adult supervision is necessary when changing and disposing of batteries.
2. Make sure to turn switch "OFF" when changing of batteries.
3. Batteries are to be inserted with the correct polarity.
4. Non-rechargeable batteries are not to be recharged.
5. Rechargeable batteries are to be recharged.
6. Rechargeable batteries are only to be charged under adult supervision.
7. In usage, do not mix old and new batteries or batteries of different types, such as alkaline, standard (carbon-zinc) and rechargeable (nickel-cadmium or nickel metal hydride).
8. The supply terminals are not to be short-circuited under any circumstances.
9. Exhausted batteries are to be removed from the unit.
10. Replace batteries when the light is faint. Replace all batteries at the same time.
11. Only batteries of the same or equivalent type as recommended are to be used.
12. Do not allow any parts of the unit to come into contact with heat or flame.
13. Never throw batteries in a fire or attempt to open outer casing. Batteries may explode or leak.
14. Remove all batteries out if the item is left unattended for a long period.
15. LED 'S are not replaceable.

For indoor use only
Made in China