


FF27829 INSTRUCTION

PACKAGE CONTENTS

FF27829



Part	Description	Quantity	Part	Description	Quantity
A	top and rubber tube	1	D	Pump	1
B	rubber plug	1	E	base	1
C	bird	1			

PREPARATION


Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and diagram above.

Estimated Assembly Time: 30 minutes

Tools Required for Assembly: No tools needed

— ASSEMBLY INSTRUCTIONS

FF27829



Step 1: Remove the product from the box; place E on the level surface.

Step2: Connect rubber tube with (D) pump.

Step3: Put A on the support stage of E. Please note that the bayonet of A should match the mortise and tenon. The power wire line is drawing forth from E.

Step4: Pouring the water in it. Make the water surface abreast with the support platform.

Step5: Switch on and turn on it, the product is set to work. If the running water is not asymmetry. Please dab the water surface.

二、 Care and maintenance

- 1、 Please change the water and do the cleaning on a regular basis. Don't make the water go bad, clamminess and produce microorganism.
- 2、 Please replenish clean water and keep the water level flooding the pump.
- 3、 If you don't use the fountain for a long time. Please make the power off and dry the water.

三、 Warning:

- 1、 Please keep away from babies and pet.
- 2、 Please keep the power line away from the high temperature.
- 3、 This fountain can be used both indoors and outdoors .
- 4、 Please use the power supply that match the transformer nameplate.