

TROUBLE SHOOTING INSTRUCTIONS FOR PRE-LIT TREES

(If your tree is unlit, please disregard below instruction)


If Lights Do Not Work:

1. Check whether the cord is properly plugged into the outlet.
2. Be sure there is power to the outlet.
3. Check whether all plugs within the tree are securely connected.
4. Check whether all bulbs are tightly fixed inside the lamp holders.
5. If a bulb is blown, replace the faulty bulb following the below diagram.


There are spare bulbs included for easy replacement.



6. If none of the lights are working, check the fuse in light string. If the fuse is blown, replace the blown fuse following the below diagram. There are spare fuses included for easy replacement.



7. If none of the lights are working, check the fuse in extension cord. If fuse is blown, replace the blown fuse following the below diagram. There is a spare fuse included for easy replacement.



WARNING – Risk of Fire and Electric Shock:

1. Read all instructions and warning tags included with this tree.
2. For Indoor Use Only.
3. Do not place near gas or electric heaters, radiator, fireplaces, candles, or other similar sources of heat.
4. Place on a level, hard, flat surface; do not place where tree is likely to wobble due to uneven floors or thick carpeting.
5. Do not use candles on tree.
6. After assembling the tree and adding decorations, make sure the tree is stable. If tree is not stable, shift the weight of decorations, and use support wires to walls and/or window frames (make sure they are secure also).
7. Do not overload extension cords or power strips, see ratings on those devices and check the rating label of the tree for compatibility.
8. Do not install near fountains, bathtubs, sinks, or other wet areas.